

INBody230 Repacking Instructions

1. Spread out all the bubble padding.



2. From the folded position, place the InBody in the box.



3. Fold down the side bubble padding.



4. On both sides.



5. Pull the long bubble padding over the InBody.



6. Tuck the bubble padding over the LCD and under.



7. Place your power adapter and power cord on top of the long bubble padding.

